

leva preventative maintenance checklist.

	Customer:				date:	
	machine data					
	Serial Number:		Voltage:		N. groups:	
	check water quality	(the sample of water must be taken at the pump)				
	Filter in use: Chlorides:		Total hardness: Alkalinity:		PH: TDS:	
	3-4 months maintena	ance				
	Inspect drain box and Check all buttons for Check group switche Check spring system Check cam and lever Check for tighteness Check pre-infusion p Check max pressure Check expansion valve that group sip Check steam valves to Check fittings and valves for the check fittings for the check fit	eens and springs condition d hose for leaks or clogs r proper operation es for proper operation for wear and proper operation r system for wear and proper operatio of the levers screws eressure for each group we operation (remove cup tray to reach pressur whon is clean for proper operation	G1:	<i>bar</i> G2 nulation on probe:	brewing pressection bar coffee boiler max pressection low med [G3: bar
	6 months maintenance (in addition to the above)					
	Replace filter basket If S, fit steam valve					
	1 year maintenance (in addition to the above)					
	Inspect solenoid valve Replace vacuum breat Inspect expansion vacuum Inspect electrical wire Replace safety valve Rebuild piston assent Bleed all groups	akers alve ring condition nbly on each group				
	2 year maintenance (in addition to the above)					
	Rebuild stem seals assembly on each group					
	3 years maintenance (in addition to the above)					
	Replace spring stem guide rings on each group Replace cam wheel on each group Replace lever mechanism rollers on each group Check the condition of boilers and, if necessary, take them out for proper descaling.					
	Further checks may be necessary based on machine's general conditions.					
	Notes:			Parts re _r	olaced:	
	Technician signature			Custome	er signature	