

Preventative Maintenance Checklist

GS3 6 Month

Please fill out all sections completely	7.			7
Customer Name:	Service Provider:			
Phone:	Technician:			
Address:	Other Parts Used:			
Serial Number:				
All Models				
☐ Clean and Back Flush Machine☐ Replace Group Gaskets☐ Replace Diffuser Screens (F.3.040)	□ 8 mm (H.3.001))	□ 9 mm (L105/B9)	
☐ Test Flow Rate	Group 1:	-		
☐ Test Brew Temperature Setting	Desired:		Current:	
☐ Test Brew Pressure Setting				
 □ Test All Switches for Proper Operation □ Test Steam Boiler Vacuum Breaker for Proper Operation □ Inspect Drain System □ Test Water with La Marzocco Water Test Kit (F.9.000) 	☐ Replaced ☐ Replaced	☐ Acceptable ☐ Acceptable		
If AV Model ☐ Test Shot Volumes ☐ Test Flow Meter for Correct Resistance	Group 1:	_		
If MP Model* ☐ Rebuild MP Valve (SA/600K) — only required on older models of the GS3 MP. New GS3 MPs with a conical valve do not need to be rebuilt this frequently. Contact @christopher@lamarzocco.com for questions.				
Notes:				
Technician (Please Print):				
Technician Signature				