
swift mini quick start guide

WWW.LAMARZOCCO.COM

VIA LA TORRE 14/H 50038 SCARPERIA E SAN PIERO FLORENCE - ITALY







unpacking & set up, loading coffee, grinding coffee

Open the hopper.

Swing the upper part of the Swift Mini


unpacking & set up, loading

and grinding coffee tutorial

and rotate it 45° clockwise.

single dose, filter grind, your own dose

Please note, do not use 7gr baskets.



Remove the grinder from its box and place it on the counter.


Load coffee and lock the lid (slides back in

Lift the lock lever placed behind the

see full tech documentation

hopper to unlock the swing-arm.

position).




Insert the hopper in its position and lock it by turning it clockwise (it will 'click').

Gently insert the portafilter.

Pull down the lock lever to lock the

swing-arm in the new position.


Do not use 7gr baskets.




activating the main power switch (placed under the base).

When the light on the button is green, press it

to grind coffee.




Open the hopper lid (it will slide backwards).




Remove the portafilter and lock it to the



If you wish to grind for filter coffee, change the coffee grind (likely to have to make it coarser), press the button and grind directly into the desired container.







To increase the coffee dose, turn the


bottom wheel counterclockwise.

Close the hopper and remove it by turning it counterclockwise and lifting it.




Use the brush to clean the lower part of Use the brush to clean the top burr.







Pull down the impeller wheel to clean it.




Insert back the grinding channel and its lid by following the guides.




by attaching it to the grinder with its own magnet by following the hexagonal guide.




setting grind and dose




When brewing coffee remember that a good starting point for a double espresso is a volume of 28-34 cc (1 oz) extracted in approximately 25-30 sec, unless otherwise stated on your coffee bag.




25-30 sec you are likely to have a too coarse grind and need to adjust it to make it finer. Adjust the grind by rotating the top wheel counterclockwise.




If the extraction time is slower that 25-30 sec you are likely to have a too fine grind and need to adjust it to make it coarser. Adjust the grind by rotating the top wheel clockwise.



Repeat this procedure until you extract the desired volume in the correct time.



you DO NOT need to purge the grinder, but the adjustment is immediately effective.



To decrease the coffee dose, turn the bottom wheel clockwise.



Repeat this procedure until you have reached the desired coffee dose.

maintenance


With the help of an external scale, you


inside your filter basket according to

may need to adjust the coffee dose

specific coffee recipes.

Move the swing-arm as if you were to grind for single dose / filter, from this position you'll be able to clean burrs, grinding channel, impeller wheel.





Attach the hopper and move back the

After the procedure if you bring back the adjustment wheel to the same number you will get the same grinding without needing to re-adjust the grind.



setting grind and dose



If you wish to grind for single dose

baskets (7gr), press the button and

grind directly into the 7gr filter basket.

grind



single dose and filter



maintenance tutorial